

Cold Source Engineering:

Operation and Upgrade of the BT-9 Cold Source,
Nicknamed “PeeWee”

James Torres

B.S. Physics, Rowan University

Mentor: Michael Middleton


Director: Julie Borchers

NIST




Overview

1. What is PeeWee?
2. What is an issue currently needing resolution?
3. What is the solution?




What is PeeWee?




PeeWee = BT-9 Cold Source



Multi-Axis Crystal Spectrometer
(MACS)



National Bureau of Standards Reactor (NBSR)



Heavy Water

Helium Gas


Vacuum

Liquid Hydrogen

Vapor out

Liquid in

Cryostat



Thermal Neutrons 2 \AA





20 K Cold Source



Cold Neutrons 6 \AA


2000 Researchers

99% CNS Operation




Overview

1. What is PeeWee?
2. What is an issue currently needing resolution?
 - **PeeWee condenser helium temperature**
3. What is the solution?



Cold Source Overview

RX POWER 19.688 MW




Low Mass Flow Rate

2 atmospheres
b.p. ~ 22.9 K

Thermosiphon

Neutrons from core



Hydrogen System

ALARMS BYPASSED

| Cold Source Status | | |
|-------------------------|--------|-------|
| Reactor Power | 9.4E-5 | MW |
| Calc Heat Load | 5.6E-3 | W |
| Cryostat Cooling Status | | |
| D2O Temp In | 26.3 | C |
| D2O Temp Out | 26.8 | C |
| D2O Flow A | 1E-2 | GPM |
| D2O Flow B | -0.6 | GPM |
| Cryostat Heat | 1.7E-3 | kW |
| Hydrogen Detectors | | |
| HD3 | 36 | % LFL |
| HD4 | 36 | % LFL |

Hydrogen Gas Management System

System Pressures (kPa)

Hydrogen P101A -301

Hydrogen P101B -301

Hydrogen P102A 0.0


Hydrogen P102B -258

He Containment P105 0.0

Helium Manifold P106 0.0

Overview


1. What is PeeWee?
2. What is an issue currently needing resolution?
 - **PeeWee condenser helium temperature**
3. What is the solution?
 - **Bypass + Valve**



Cold Source Overview


RX POWER 19.688 MW

Refrigeration Cycle




Upgrade

Bypass Valve




C100 Photo

CV452






CreoElements 3D Model





PHPK Manual

Valtek Actuator PHPK Valve



Valtek Flowserve Brochure



PHPK manual



Positioner



Flowserve

Left: Beta Positioner


Right: NT3000 Electro-Pneumatic Transducer



Transducer & Positioner Operation



I/P MODULE
Transducer






Beta Positioner

Limit Switch



Flowserve
Position Pac

Manual adjustment
of LS cam and lever





P-Proportional
I-Integral - Controller
D-Derivative

$$\text{Error} = e = SP - PV$$

$$CV(t) = K_p \cdot e(t) + K_i \cdot \int_0^t e(\tau) d\tau + K_d \cdot \frac{d}{dt} (e(t))$$

Present Past Future




PID controller block used in RS LOGIX 5000

Closing

October 18 – November 11

- Wire Diagrams; [creating, updating, and reading](#)
- Soldering
- Pin Connectors
- RS LOGIX 5000 [ladder logic programming software](#)
- Creo Elements [solid modeling software](#)
- MakerBot [3D printer](#)
- Helium Mass Spectrometry [for vacuum testing](#)
- Vacuum Gauge; [testing and calibrating vacuum range](#)
- Calibrator [for a dummy signal in testing valve position](#)



Thank you,

NIST



Michael Middleton

Robert Williams

Mike Rowe

Julie Borchers

Terrell Vanderah

Robert Shull

SURF